

How to store/restore the PDU's settings for mass configuration?

You can use PDU Fitility to approach this

- 1. Export system profile
 - 1-1. Select the PDU that you want to download the configuration
 - 1-2. Click the Backup icon function




1-3. Input the user name and password for this PDU




1-4. Click Export button




1-5. Input the path and file name for this profile and click Next button



1-6. Click Continue to go head the export process




1-7. Export successfully




2. Import system profile to other PDUs


2-1. Select the PDUs that you want to import the profile, then click the Backup function




2-2. Input their user name and password then click Next




2-3. Click Import



2-4. Select the profile you backup earlier then click Next



2-5. Click Continue



2-6.Done